



www.vac-rac.com

info@vac-rac.com

COMBI - INSTRUCTIONS



For use on **steel** vehicles.

Please read and follow carefully.

- Insert threaded ends of “T”s in bases and tighten.
- Ensure bases and vehicle are clean.
- Press the rack with double elastics on flat area of hood/bonnet, without gaps, on **passenger side**.
- Place the other rack on a flat area of roof.
- Pressing down expels air – make sure **all** edges of the base are in contact with the vehicle.
- Attach rods with reels forward and loop elastics over bar ends.
- Elastic tension can be adjusted using the teeth under the bar.
- Check for security by pulling gently on the “T”.
- Remove rods by inserting finger in bar recess and sliding elastic over end.
- Use pull tabs to remove racks from the vehicle.

IMPORTANT NOTES

- COMBI racks are designed for fishing rods only and should be removed after use.
- Not for use on ice covered vehicles. Wet vehicles – wipe off excess water.
- The longer a Combi is attached the more secure it becomes – air and water are gradually expelled.
- Cars parked under trees, long term, can build up aphid deposits.
- Protect your rods by not driving at high speed.
- **Storage:** Keep your racks clean and flat by joining them face to face.
- **NB.** If you change your vehicle, check your new one has **steel** bodywork!