



[www.vac-rac.com](http://www.vac-rac.com)

[info@vac-rac.com](mailto:info@vac-rac.com)

## LOC RAC – INSTRUCTIONS



## Please read and follow carefully.

- Insert threaded ends of “T”s in bases and tighten.
- Insert levers into bases.
- Make sure levers are in the **OFF** position.
- Ensure bases and vehicles are clean.
- Press rack with double elastics on **flat area** of hood/bonnet on **passenger side**.  
Operate lever and remove it.
- Place the other rack on a flat area of roof or windshield.
- Attach rods with reels forward and loop elastics over bar ends.
- Elastic tension can be adjusted using the teeth under the bar.
- Check for security by pulling on the base, not the “T”.
- Remove rods by inserting a finger in bar recess and sliding elastics over the end.
- To remove racks from vehicle, undo lever and pull the tab to break the vacuum.

## IMPORTANT NOTES

- When not in use, fit the protective covers and keep the levers in the **OFF** position.
- Loc Racs are designed for fishing rods only and should be removed after use.
- Not for use on ice covered vehicles. Wet vehicles – wipe off excess water.
- Cars parked under trees, long term, can build up aphid deposits.
- Protect your rods by not driving at high speed.
- **Keep one key as spare – it can be fitted to a key ring. Put some bright string on the other key.**
- If you accidentally deform the bases, put them on a smooth clean surface with the levers in **UP/OFF** position. (They will gradually return to their shape at room temperature).