



www.vac-rac.com

info@vac-rac.com

PRO LOC - INSTRUCTIONS



For use on all vehicles.

Please read and follow carefully.

- Ensure bases and paintwork are clean, and scratch free.
- Attach bases to T bars and tighten.
- Bases may be moistened before use.
- Make sure levers are in the **OFF** position.
- Place rack on **flat area** of hood/bonnet on **passenger side**.
- Place the other on the roof.
- Press on one cap, operate the lever.
- If necessary push in the other base to ensure it sits flat on the surface and repeat.
- Check for security by pulling on caps. **Remove levers.**
- Do not pull horizontal bars.
- Check that racks are secure between trips.
- Attach rods by looping straps over bar ends and centre pillar.
- To remove, undo lever and pull the release tabs.

IMPORTANT NOTES

- Vac Racs are designed for fishing rods only and should be removed after use.
- Not for use on ice covered vehicles. Wet vehicles – wipe off excess water.
- Cars parked under trees, long term, can build up aphid deposits.
- To avoid rod whipping do not drive at high speed.
- For **storage** fit the protective base covers and make sure the levers are in the **OFF** position.
- Don't lose the levers – put one on a keyring – bright string on the others.